



P.14
CROSSHEAD

P.17
UPPER TOGGLE
ARM PIN

P.013
CRANK BOX
AND PITMAN

P.04
CRANK PLATE AND PIN

P.9M
CRANKSHAFT

P.012R
TOGGLE ARM
(RIGHT)

P.06M
FRICTION SPIDER

P.012L
TOGGLE ARM
(LEFT)

P.5M
FRICTION
PULLEY

P.015
TENSION SPRING

P.11
SHIFTING COLLAR

P.35
TENSION
ADJUSTING
SCREW

P.29
SHIFTING FORK

P.019
TOGGLE LINK

P.28
BOX CAP
REAR

P.002
RAM

P.27
BOX CAP
FRONT

P.7
UPPER DIE

P.18
LOWER TOGGLE
ARM PIN

P.8
LOWER DIE

P.003R
RAM GUIDE

P.33
KEY FOR
LOWER DIE

P.38, P.38W
RAM GUIDE
BOLT AND
WASHER

P.031
DIE BLOCK

P.34
DIE BLOCK KEY

P.001
FRAME

P.23
TREAD BOLT

P.22
FOOT TREAD